

Vehicle Inspection Item

Last Modified on 08/19/2025 11:47 am PDT

Pathway: Setup > Operations > Vehicle Inspection Item

The **Vehicle Inspection Item** screen lists all possible items that can be required for vehicle inspections recorded by a driver in NavuNav. Items added here will not appear in the Vehicle Inspection list until they are activated in the **Vehicle Inspection Type** screen.

VEHICLE INSPECTION ITEM SETUP			SETUP > OPERATIONS > VEHICLE INSPECTION ITEM
<div><div></div></div>			<div></div>
ID	QUESTION	REQUIRED	
1000	Tires, Wheels, and Rims	Yes	
1001	Power Steering & Auto Trans Fluid	Yes	
1002	Engine Oil, Fuel, and Coolant	Yes	
1003	Service Brakes and All Connections	Yes	
1004	Parking (hand) Brakes(s)	Yes	
1005	Steering Mechanism(s)	Yes	
1006	Horn(s), backup alarm, rail-up alarm	Yes	
1007	Instruments and Gauges	Yes	
1008	Lights and Reflectors	Yes	
Vehicle Inspection Item Option			
<div><div></div></div>			
ID	NAME ↑		
1004	Cracks, Cuts or Damage		
1000	Flat		
1005	Grease Leaks		
1003	Loose Lug Nuts		
1001	Low Air Pressure		
1002	Marginal Tread		

Permissions

The following permission is required to access the Vehicle Inspection Item screen to add and edit items.

Permission ID	Permission Name
24	Setup \ Operations

Add a New Item

Select the Add icon to open the Add Vehicle Inspection Item popup editor. Enter the item in the Question field—this is what the driver will see—and choose whether the item will be required. Once the item has been added and saved, you can add item options, as described in the next section.

VEHICLE INSPECTION ITEM SETUP

SETUP > OPERATIONS > VEHICLE INSPECTION ITEM

+

ID	QUESTION	REQUIRED
1000	Tires, Wheels, and Rims	Yes
1001	Power Steering & Auto Trans Fluid	Yes
1002	Engine Oil, Fuel, and Coolant	Yes
1003		Yes
1004		Yes
1005		Yes
1006		Yes
1007		Yes
1008		Yes
1009		Yes
1010		Yes
1011		Yes
1012		No
1013		Yes
1014	Vehicle Damage	Yes

ADD VEHICLE INPSECTION ITEM

QUESTION

REQUIRED

No

SAVE

Vehicle Inspection Item Option

Add a Vehicle Inspection Item Option

After adding an inspection item in the upper grid, select it to define options in the lower grid. These options appear as checkboxes for the driver to indicate the reason an item failed during the pre- or post-trip inspection.

VEHICLE INSPECTION ITEM SETUP

SETUP > OPERATIONS > VEHICLE INSPECTION ITEM

+

ID	QUESTION	REQUIRED
1000	Tires, Wheels, and Rims	Yes
1001	Power Steering & Auto Trans Fluid	Yes
1002	Engine Oil, Fuel, and Coolant	Yes
1003	Service Brakes and All Connections	Yes
1004	Parking (hand) Brakes(s)	Yes
1005	Steering Mechanism(s)	Yes
1006	Horn(s), backup alarm, rail-up alarm	Yes
1007	Instruments and Gauges	Yes
1008	Lights and Reflectors	Yes

Vehicle Inspection Item Option

+

ID	NAME ↑
1004	Cracks, Cuts or Damage
1000	Flat
1005	Grease Leaks
1003	Loose Lug Nuts

ADD VEHICLE INPSECTION ITEM OPTION


VEHICLE INSPECTION ITEM

1000

OPTION NAME

SAVE

NavuNav (Android example)



Related Articles

Review the following article to complete the setup of vehicle inspections.

[Vehicle Inspection Type](#)