
Truck Type

Last Modified on 10/12/2026 7:53 am PDT

Pathway: *Setup > Operations > Truck Type*

Truck Type Setup establishes and defines the distinct types of trucks utilized within the system and assists in turn-by-turn navigation by restricting the road options available to a specific truck type. This setup process further involves assigning specific truck types to individual trucks within *Setup > Operations > Truck*.



Permissions

The following permission is required to access and work within the Truck Type Setup screen:

Permission ID	Permission Name
24	Setup \ Operations

Truck Type Setup Field Descriptions

Fields	Descriptions
Name *Required*	The name of the Truck Type.
External ID	The identification number used by third party systems.
Transport Method *Required*	Select 'Truck'.
Require Equipment Count	The number of those truck types being entered into the system.
Tare Frequency	The number of days before trucks of this type must be re-weighed. Once a truck reacl this threshold, it will be flagged, and the scale operator must record the tare weight tc complete the ticket.

Height	The standard height for trucks of this type.
Width	The standard width for trucks of this type.
Size UOM	Specifies the unit for height and width measurements.
Road Weight	The approximate weight for trucks of this type.
Maximum Weight	The highest weight the truck can reach when completely loaded with waste.
Weight UOM	The unit of measure used for the weight measurement.
Active	Indicates if the truck type is available for assignment to a truck.

Truck Type Setup Steps

1. Select the **green +** to open Add Truck Setup.
2. Complete the following required fields:
    - Enter a **Name** for the truck type.
    - Select the **Transport Method** for the truck type.
3. Complete additional fields based on your company's setup requirements.
4. Click **Save** when finished.

Related Articles

Truck Setup